

Damage: a broken piece of plastic



■ Fix both parts




Grind a V-groove (1 cm approx.) into the side edges, use 80 grit sandpaper



■ Fill up the break with adhesive




Clean entire work area using Sika® Cleaner G+P. making sure the surface is completely dry and no moisture remains



■ Bend the film and compress adhesive and wait for adhesive to be cured according to product label




Spray a thin coat of Plastic Primer on both sides, flash-off for 5 min¹⁾




Before attaching mixer, extrude some material until both parts A and B flow evenly

Attach static mixer and dispense one third of mixer length



Position the broken part on the Sika Contouring Film and apply Plastic Adhesive Superfast on the breaking





PLASTIC ADHESIVE SUPERFAST SikaForce®-302			
Article No.	736291		
Working Time ¹⁾	90 sec		
Clamp Time ¹⁾	5 min		
Sanding Time ¹⁾	10 min		
Content	50 ml + 3 mixers		
Mixing Ratio	1:1		
Color	Black		

ACCESSORIES	Article No.	Content	Box Content
Sika® Cleaner G+P	527420	500 ml	12 pc
SikaForce®-300 Primer	736000	200 ml	6 pc
Sika Contouring Film	505296	360 cm	30 pc
Sika Reinforcement Mesh	505297	360 cm	20 pc
Sika Mixer Quadro 73mm	751521	12 pc / bag	20 bags
Sika Dispensing Gun	512113	-	1

Our most current General Sales Conditions shall apply. Please consult the most current local Product Data Sheets prior to any use.

